



RT26 Wristband transmitter

The RT26 wristband transmitter has been specially adapted to the requirements of people in need of care. The large push button makes it easy to operate.

Switching electrical devices on and off with a 1-button operation or activating paging systems are among the standard application areas of this transmitter.

An LED indicates if the battery needs to be changed. If the battery is running low, a separate radio signal is transmitted which can be analyzed by a corresponding Easywave receiver.



RT26E5001-12-23K

Technical specifications

Coding	factory coding with Easywave telegram	
Frequency	868.30 MHz	
Channels	1	
Range	typically 150 m in good free-field conditions	
Power supply	1x 3V battery, CR2032	
Operating indicator	LED	
Operation	transmission lasts as long as the button is pressed (maximum 36 seconds)	
Function	depends on the receiver (see models)	
Protection degree	IP65	
Operating temperature	-20 °C to +60 °C	
Dimensions	38 x 46 x 14 mm	
Weight	16 g (including battery, without wristband)	
Color	anthracite gray similar to RAL 7016	

Scope of delivery

- Wristband transmitter
 including battery
- Wrist strap (nickel-free clasp)
- Operating manual

Accessories (optional)

RT26-ACC-02-23PWrist strap (nickel-free clasp)ACC-TOO-01-23PRound housing keyACC-SEA-01-00PxO-ring seal







Models

Product numbers	Description	Function
RT26E5001-12-23K	Wristband transmitter 1-channel, anthracite gray, red button	1x PULSE

RADIO SYSTEMS:

Flexibility

Convenience

Energy efficiency Security

ELDAT EaS GmbH · Schmiedestraße 2 · D-15745 Wildau · fon +49(0)3375 9037-0 · fax +49(0)3375 9037-9 · info@eldat.de · www.eldat.de